



ACS100 Quick Start Guide

Connecting and Configuring Your ACS100



Yellow - Door Contact
Blue - REX
Brown - Lock Power
Red - 12V Out (Power)
Black - GND



STEP 1

Connect door wiring to your hardware



STEP 2

Plug the ACS100 into your network via PoE;
allow it to boot



STEP 3

Mount the ACS100 to junction box or wall using included screws and hardware



STEP 4

Configure your ACS100 online at brivo.com/onair-login

NEED MORE INFORMATION?

The complete ACS100 Installation Guide
is available online at brivo.com/techdocs

The product is designated for indoor and outdoor use.
Follow safe handling and installation precautions at all times.